DEVICE MENUS VERSION 72

THE POWERBOLT MENU

Hot Keys

up/down button press: e-give control

power/down button press: hard reset

Power Button: turn device on/off (U)

- White: indicates battery charge level
- Blue: adjust eGive level (use 'up' and 'down' to control) (
- Yellow: turn Bluetooth on/off
- Green: set voltage resolution from 0.1 to 0.5 voltage steps
- **Orange:** automatic LED brightness dimming (*enable/disable*)
- Light Blue: manual LED brightness control (use 'up' and 'down' to control) (
- **Red:** shipping mode

POWERBOLT +, LIGHTNINGBOLT, LIGHTNINGBOLT UNI, AIRBOLT, AIRBOLT MINI MENU

Hot Keys

up/down button press: e-give control

up/down button press/hold (for at least 3 seconds): footswitch pairing power/down button press: hard reset

Power Button: turn device on/off

- White: indicates battery charge level
- Blue: adjust eGive level (use 'up' and 'down' to control) (
- **Green:** set voltage resolution from 0.1 to 0.5 voltage steps
- **Orange:** automatic LED brightness dimming (*enable/disable*)
- Light Blue: manual LED brightness control (use 'up' and 'down' to control)
- **Pink:** sync or un-sync footswitch (for compatible devices)
- Red: shipping mode





