

Professional Client Chair & Hybrix Client Chair pump brake adjustment

1. Put pump in highest position. Take off pump upper cover.
2. Release with Key 14. Adjust brake with key 17 to desired tightness.
3. Then tighten key 14 back. Put cover back.

