

# EQUALISER PROTON MACHINE

## USER MANUAL

### Technical details:

- Stroke: 3,5mm
- Motor power: 5W - Mabuchi MOTOR
- Adjustable extension of needle 0-4,5mm
- Connection: RCA
- Grip diameter: 25mm
- Operating voltage from 7 to 11V

### Maintenance:

There is no need to lubricate the machine. Only the rubber O-rings at the handle should be lubricated with a super lube approx. every 400-500 hours.

### Connection:


Use only high quality RCA cable with positive polarity on the inner pin.

**NOTE:** We highly recommend using cartridges with protective membrane only. Use other types of cartridges at your own risk.

### Warranty:

EQUALISER Proton machine has a 1 year warranty, calculated from the date of purchase which covers all parts provided that the machine is used as intended. The guarantee does not include mechanical damage and flooding the machine.

Correct cable&power suply polarization to LED lights:



### **In case of spring damage**

Use the key to uscrew the nut

Change the spring

Tighten the nut

