

Repair of lamp in the A4-thermocopier

Unplug machine from power by removing the power-cord !!

Step 01: open four torx-screws on front and rear of case

Step 02: set speed-control to 3 and tear away the black speedcontrol-knob

Step 03: lift off the cover and remove the grounding-cable from the case

Step 04: remove both cables for the lamp by pressing the plastic-triggers and tearing out the cables (left arrows in picture 1)



picture 1

Step 05: carefully tear cable for the right side of the lamp through the cable-tunnel (lower arrow in picture 2)

Step 06: open 2 torx-screws centering the lamp at the end of the reflector (upper arrow, but not shown in picture 2 !)



picture 2

Step 07: tear out the lamp towards the right side – make sure that the cables follow well

For mounting the new lamp please work in opposite order. Handle lamp carefully and don't touch the glass, only the porcelaine-ends.

Make sure that the cables are both positioned without contact to other parts and without contact with sharp edges.

Be sure to connect the grouding-cable to the case before closing the case of the machine!